


Pos.	Part number	Name	Pos.	Part number	Name
1	AF-B - 02.00.00.01	Slide	34	ISO 8750-3x20-St	Spiral spring pin (3x)
2	AF-B - 02.00.00.01-01	Slide Optic Ready (Shield)	35	AF-B - 01.02.00.04	Trigger bar spring
3	AF-B - 02.00.00.02-01	Barrel	36	AF-B - 01.01.00.02	Magazine catch
4	AF-B - 02.00.00.02-02	Barrel 13.5x1L	37	AF-B - 01.01.00.03	Magazine catch spring
5	AF-B - 02.00.00.02-03	Barrel 1/2x28tpi	38	AF-B - 01.01.00.08	Magazine catch button
6	AF-B - 02.00.00.03	Locking block	39	AF-B - 01.01.00.09	Magazine button plate
7	AF-B - 02.00.00.04	Extractor	40	ISO 14581-M3x8	Screw
8	AF-B - 02.00.00.05-02	Firing pin	41	AF-B - 01.01.00.05	Magazine catch pin
9	AF-B - 02.00.00.06	Firing pin rebound spring	42	ISO 8750-3x26-St	Spiral spring pin
10	AF-B - 02.00.00.07	Pin of safety firing pin	43	ISO 8750-3x16-St	Spiral spring pin
11	AF-B - 02.00.00.08	Safety firing pin	44	AF-B - 01.02.00.01	Frame
12	AF-B - 02.00.00.09	Safety firing pin spring	45	AF-B - 01.00.00.04	Main pin
13	AF-B - 02.00.00.10-01	Slide cover plate	46	AF-B - 01.00.00.01	Ejector
14	AF-B - 02.00.00.11	Frong sight	47	AF-B - 01.00.00.02	Slide stop
15	AF-B - 02.00.00.12	Rear sight	48	AF-B - 01.00.00.03	Slide stop spring
16	AF-B - 02.00.00.13	Front sight screw	49	AF-B - 01.02.00.03	Sear pin holder
17	ISO 4026 M3x5	Screw (2x)	50	AF-B - 01.02.00.06	Trigger safety pin stop
18	AF-B - 02.01.00.01	Firing pin guiding sleeve	51	AF-B - 01.02.00.02-01	Sear
19	AF-B - 02.01.00.02	Firing pin spring	52	AF-B - 01.02.02.01	Sear spring pin
20	AF-B - 02.01.00.03	Firing pin spring guide	53	AF-B - 01.02.02.02	Sear spring
21	AF-B - 02.02.00.01	Extractor spring	54	AF-B - 01.02.01.01	Trigger safety
22	AF-B - 02.02.00.02	Extractor plunger	55	AF-B - 01.02.01.02	Trigger bar
23	AF-B - 02.02.00.03	Extractor spring guide assy	56	AF-B - 01.02.01.03	Trigger
24	AF-B - 02.00.00.14	Shield cover plate	57	AF-B - 01.02.01.014	Trigger spring
25	ISO 14581-M3x4	Screw	58	ISO 8750-2x10-St	Spiral spring pin
26	AF-B - 02.02.03.00	Recoil mechanism assy	59	AF-B - 01.02.03.01	Trigger spring rod
27	AF-C - 01.01.00.01-02	Grip	60	AF-B - 01.02.03.02	Trigger safety spring
28	AF-C - 01.01.00.02-02	Grip extension	61	AF-B - 01.02.00.05	Trigger safety pin
29	AF-C - 01.01.00.03-02	Grip extension magwel	62	AF-B - 01.02.00.07	Main pin spring holder
30	AF-C - 01.01.00.04-02	Backstrap C1	63	AF-B - 03.00.00.00	Magazine 15 RD assy
31	AF-C - 01.01.00.05-02	Backstrap B1	64	AF-A - 03.00.00.00	Magazine 18 RD assy
32	AF-C - 01.01.00.06-02	Backstrap B3	65	AF-C - 03.00.00.00	Magazine 12 RD assy
33	AF-C - 01.01.00.07-02	Backstrap A1			




56
54
55
61
62
60
57
58
35
51
59
52
53
44
50
48
49
46
45
47
43
37
38
36
42
27
30
31
32
33
39
40
41
34
28
29
65
63
64


№23 Extractor spring guide assy



Pos	Part number	Name
23a	AF-B - 02.02.01.01	Extractor spring guide
23b	ISO 8750-2,5x6-St	Spiral spring pin

№26 Recoil mechanism assy

Pos	Part number	Name	Pos	Part number	Name
26a	AF-B - 02.02.03.01	Rod recoil mechanism	26e	AF-B - 02.02.03.07	Recoil spring middle
26b	AF-B - 02.02.03.02	Rod recoil mechanism plate	26f	AF-B - 02.02.03.04	Recoil mechanism sleeve big
26c	AF-B - 02.02.03.08	Recoil spring small	26g	AF-B - 02.02.03.05	Rod recoil mechanism nut
26d	AF-B - 02.02.03.03	Recoil mechanism sleeve small	26h	AF-B - 02.02.03.06	Recoil spring big



№63 №64 №65 Magazines assy

Pos	Name	Pos	Name
63a	Magazine tube 15RD	63b	Magazine follower
64a	Magazine tube 18RD	63c	Magazine spring
65a	Magazine tube 12RD	63d	Magazine plate

